

■ Specification

Model	OB-LX700IR100L2812-W
Pick up Element	1/3" SONY Super HAD CCD II
Effective Picture Elements (H×V)	NTSC:976(H)×494(V) PAL:976(H)×582(V)
Horizontal Resolution	700 TV Line
Minimum Illumination	0.001 Lux/F1.2 0Lux (with IR LED ON)
S/N Ratio	More than 52dB
Scanning System	2:1 interface
Synchronous System	Internal, Negative sync.
Auto Electronic Shutter	NTSC: 1/60s~1/100,000s, PAL: 1/50s~1/100,000s
Gama Characteristic	0.45
IR Distance	40 Meters (with ϕ 5X42 PCS Infrared LED)
Video Output	1Vpp, 75 Ω
Auto Gain Control	Auto
Power/Current	DC12V(+/-10%)/500mA
Lens	2.8-12mm Manual Zoom Lens
Dimension (mm)	260(W)x112(H)x85(D)
Weight (g)	1600
Storage Temperature	-30~+60°C RH95% MAX
Operating Temperature	-10~+50°C RH95% MAX


■ Packing List

No	Name	Model	Number
1.	Weatherproof IR Color Camera	OB-LX700IR100L2812-W	1
2.	User Guide	OB-LX700IR100L2812-W	1

Franchiser:

OB-LX700IR100L2812-W Color Camera

Weatherproof IR Color Camera



Notes : Before providing power for the camera, please read this User Guide in detail!

Do not attempt to disassemble the camera. If the camera can not work, please contact local franchiser or our company.

BRIEF OF PRODUCT

* Sensor (CCD)

Adopt SONY 1/3" CCD Sensor.

* Auto Gain Control (AGC)

Built-in auto gain control (AGC) circuit. The color camera can get high definition picture in low Lux condition.

* Scanning Mode

NTSC or PAL mode.


* Water Resistance

IP66

* OSD SETTING

	LENS	MANUAL	
		AUTO	TYPE:DC/VIDEO
SHUTTER/AGC	AUTO	AUTO	MODE:CLOSE/AUTO/OPEN SPEED:0-255
			HIGH LUMINANCE MODE:SHUT+AUTO IRIS/AUTO IRIS
			BRIGHTNESS:0-255
	MANUAL	MANUAL	LOW LUMINANCE MODE:OFF/AGC
			BRIGHTNESS: ×0.25, ×0.5, ×0.75, ×1
			MODE:SHUT+AGC
WHITE BAL	ATW	ATW	SHUTTER:1/50,1/120,1/250,1/500,1/1000,1/2000,1/4000,1/10000
			AGC:6,12,18,24,30,36,42,44,8
BACK LIGHT			SPEED/DELAY CNT/ATW FRAME/ENVIRONMENT
PICT ADJUST			PUSH/ANTI CR/PUSH LOCK/USER1/USER2/MANUL
ATR	OFF		MORROR/BRIGHTNESS/CONTRAST/SHARPNESS/HUE/GAIN
	ON		LUMINANCE/CONTRAST
MOTION DET	OFF		
	ON		DETECT SENCE/BLOCK DISP/MONITOR AREA/ AREA SEL/TOP/BOTTOM/LEFT/RIGHT
PRIVACY	OFF		
	ON		AREA SEL/TOP/BOTTOM/ LEFT/RIGHT/ COLOR/TRANSP/MOSAIC
DAY/NIGHT	COLOR		
	B/W		BURST:OFF/ON
	AUTO		BURST:OFF/ON
NR	NR		DELAY CNT/DAY-NIGHT/NIGHT-DAY
CAMERA ID	OFF/ON		MODE:Y/C,OFF,Y,C
SYNC	INT		
LANGUAGE			ENGLISH/CHINESS/JAPANESS/ESPANOL/PORTUGUES/ PYCCKNN/FRANCAIS/DEUISCH
CAMERA RESET/BACK/EXIT/SAVE ALL			

CONNECTING



TROUBLE AND SOLUTION

1. No Picture after providing power

- May be the power supply voltage abnormity, please check the power supply voltage and pole whether exactitude.
- Please check all the connecting cable and monitors whether be connected correctly or not.

2. The picture level direction have flowing interference ripples

- May be caused by the power supply AC ripples, it need filter the wave of the power supply.
- Check the monitor and peripheral equipments used.

3. The picture background color changes continuously

- The fluorescent lamp's electromagnetic field cause color roll. This is proper phenomenon of the cameras.
- Reduce the fluorescent lamp numbers or increase the distance between the camera and the fluorescent lamps can improve it.
- Use power supply external sync. camera can solve it.

4. The picture smear too mass

- The power supply's voltage unstable.
- Connecting cables not connect correctly or have high impedance.



Notes:

- The power supply must through safe attestation. Its output voltage, current, voltage polarity and operating temperature must match the camera's requirement.
- When using the camera in the thunderbolt condition, please note to mount Anti-thunder device or put off the power supply plug and cable.
- In order to capture high quality pictures, the power supply's cable and video output cable should not be too long.

INTRODUCTION

Congratulations on your purchase of this product. This User Guide suits OB-LX700IR100L2812-W product. We adopt the latest SONY technical of sensor and driver. The most attractive characteristics are small and easy hidden, suits the elevator and corridor. In addition, it owns the characters of high definition and stability, strong anti-jamming, rich and real color. Fixing and using this model are convenient too. It is very good for you to apply to your CCTV system.

Please read this instruction manual carefully to ensure proper use of the product.



The symbol is intended to alert the user to the presence of important operating and maintenance (servicing) Instructions in the literature accompanying the appliance.



The symbol is intended to alert the user to the presence of uninsulated 'dangerous voltage' within the product's enclosure that may be of sufficient Magnitude to a risk of electric shock to persons.

CAUTION:

RISK OF ELECTRIC. DO NOT OPEN

CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK

DO NOT REMOVE COVER OR BACK NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING

CAUTION: TO PREVENT ELECTRIC SHOCKS AND RISK OF FIRE HAZARDS, DO NOT USE OTHER THAN SPECIFIED POWER SOURCE.



Note:

- Please note the camera's operating temperature and its using environment requirement. Avoid using the camera at too high or too low temperatures. The operating temperature is -30~+60°C. (Recommendatory operating temperature is -10~+50°C.)
- Never make the camera face the sun or bright object. Otherwise, it will damage the CCD.
- Do not mount the camera near by the radiator or heater.