

Specification

Model	PTZ-LX700L12X
Pick up Element	1/3" SONY SUPER HAD CCD II
Effective Picture Elements (H×V)	PAL:752(H)×582(V) NTSC:768(H)×494(V)
Horizontal Resolution	650TVL (Color) / 700TVL (B/W)
Minimum Illumination	0.001 Lux
S/N Ratio	More than 52dB
Scanning System	2:1 interlace
Synchronous System	Internal, Negative sync.
Auto Electronic Shutter	PAL:1/50s~1/120000s
Gama Characteristic	0.45
Video Output	1Vpp,75 Ω
Auto Gain Control	Auto
Power/Current	12VDC(+/-10%) / 800mA
Lens	5 - 60mm Lens
Dimension(mm)	Ø138x212
Weight (g)	2800
Storage Temperature	-30~ +60℃
Operating Temperature	-10~ +50℃

Packing List

No	Name	Model	Number
1.	Weatherproof & Vandalproof Dome Color Camera	PTZ-LX700L12X	1
2.	User Guide	PTZ-LX700L12X	1

PTZ-LX700L12X Color Camera

Weatherproof & Vandalproof Dome
Color Camera



Notes : Before providing power for the camera, please read this User Guide in detail!

Do not attempt to disassemble the camera. If the camera can not work, please contact local franchiser or our company.

BRIEF OF PRODUCT

* Sensor (CCD)

Adopt SONY 1/3" CCD Sensor.

* Auto Gain Control (AGC)

Built-in auto gain control (AGC) circuit. The color camera can get high definition picture in low Lux condition.


* Water Resistance

IP66.

* OSD SETTING

OSD SET	LENS	MANUAL	
		AUTO	TYPE:DC/VIDEO
			MODE:CLOSE/AUTO/OPEN SPEED:0-255
	SHUTTER/ AGC	AUTO	HIGH LUMINANCE MODE:SHUT+AUTO IRIS/AUTO IRIS
			BRIGHTNESS:0-255
			LOW LUMINANCE MODE:OFF/AGC
			BRIGHTNESS: ×0.25, ×0.5, ×0.75, ×1
		MANUAL	MODE:SHUT+AGC
			SHUTTER:1/50,1/120,1/250,1/500,1/1000,1/2000,1/4000,1/10000
			AGC:6,12,18,24,30,36,42,44,8
	WHITE BAL	ATW	SPEED/DELAY CNT/ATW FRAME/ENVIRONMENT
			PUSH/ANTI CR/PUSH LOCK/USER1/USER2/MANUL
	BACK LIGHT	OFF/BLC/HLC	
	PICT AD- JUST	MORROR/BRIGHTNESS/CONTRAST/SHARPNESS/HUE/GAIN	
	ATR	OFF	
		ON	LUMINANCE/CONTRAST
	MOTION DET	OFF	
		ON	DETECT SENCE/BLOCK DISP/MONITOR AREA/ AREA SEL/TOP/BOTTOM/LEFT/RIGHT
	PRIVACY	OFF	
		ON	AREA SEL/TOP/BOTTOM/ LEFT/RIGHT/ COLOR/TRANSP/MOSAIC
	DAY/NIGHT	COLOR	
		B/W	BURST:OFF/ON
		AUTO	BURST:OFF/ON
	DELAY CNT/DAY-NIGHT/NIGHT-DAY		
	NR	NR	MODE:Y/C,OFF,Y,C
	CAMERA ID	OFF/ON	
	SYNC	INT	
LANGUAGE	ENGLISH/CHINESS/JAPANESS/ESPANOL/PORTUGUES/ PYCCKNN/FRANCAIS/DEUISCH		
CAMERA RESET/BACK/EXIT/SAVE ALL			

CONNECTING



TROUBLE AND SOLUTION

1. No Picture after providing power

- May be the power supply voltage abnormity, please check the power supply voltage and pole whether exactitude.
- Please check all the connecting cable and monitors whether be connected correctly or not.

2. The picture level direction have flowing interference ripples

- May be caused by the power supply AC ripples, it need filter the wave of the power supply.
- Check the monitor and peripheral equipments used.

3. The picture background color changes continuously

- The fluorescent lamp's electromagnetic field cause color roll. This is proper phenomenon of the cameras.
- Reduce the fluorescent lamp numbers or increase the distance between the camera and the fluorescent lamps can improve it.
- Use power supply external sync. camera can solve it.

4. The picture smear too mass

- The power supply's voltage unstable.
- Connecting cables not connect correctly or have high impedance.

INTRODUCTION

Congratulations on your purchase of this product. This User Guide suits PTZ-LX700L12X product. We adopt the latest SONY technical of sensor and driver. The most attractive characteristics are small and easy hidden, suits the elevator and corridor. In addition, it owns the characters of high definition and stability, strong anti-jamming, rich and real color. Fixing and using this model are convenient too. It is very good for you to apply to yours CCTV system.

Please read this instruction manual carefully to ensure proper use of the product.



The symbol is intended to alert the user to the presence of important operating and maintenance (servicing) Instructions in the literature accompanying the appliance.



The symbol is intended to alert the user to the presence of uninsulated 'dangerous voltage' within the product's enclosure that may be of sufficient Magnitude to consti- a risk of electric shock to persons.



CAUTION:

RISK OF ELECTRIC. DO NOT OPEN



SHOCK

CAUTION: TO REDUCE THE RISK OF ELECTRIC DO NOT REMOVE COVER OR BANCK NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING

CAUTION: TO PREVENT ELECTRIC SHOCKS AND RISK OF FIRE HAZARDS,DO NOT USE OTHER THAN SPECIFIED POWER SOURCE.



Note:

- Please note the camera's operating temperature and its using environment requirement. Avoid using the camera at too high or too low temperatures. The operating temperature is -30~+60℃. (Recommendatory operating temperature is -10~+50℃.)
- Never make the camera face the sun or bright object. Otherwise, it will damage the CCD.
- Do not mount the camera near by the radiator or heater.